

# **MoreMedia User Guide**

**S60 2nd Edition**

**Version 1.0**

1. User Guide	3
1.1. Overview	3
1.2. Application Start up	3
1.3. How to browse the Music / Video Catalog	3
1.3.1. Menu description	4
1.4. How to play or save media selection	4
1.4.1. Menu description	5
1.5. How to use Media player	6
1.5.1. Player commands	6
1.5.2. Volume control	6
1.5.3. Music Mode	6
1.5.4. Video Mode	7
1.6. Trial version limitations	7

## **1. User Guide**

### **1.1. Overview**

This document is the user guide for MoreMedia, an advanced media player for S60 2<sup>nd</sup> Edition, S60 2<sup>nd</sup> Edition FP1, S60 2<sup>nd</sup> Edition FP2, S60 2<sup>nd</sup> Edition FP3 phones.

MoreMedia is a Symbian C++ application running on Symbian Os version 7.0s, 8.0a and version 8.1a.

### **1.2. Application Start up**

1. Start MoreMedia Player from Application Menu;
2. Splash Screen is displayed for 1 second;
3. Home view is displayed in fullscreen mode.

Use arrows keys to switch among the following buttons:

- Music / Video: Press Ok to enter on music and video categories
- Skin: Press Ok to open Gallery and select an image as favorite application background;
- Info: Press Ok to display credits and free space on phone memory and memory card, if available

Use Left softkey to open Context Sensitive Help;

Use Right softkey to close the application

### **1.3. How to browse the Music / Video Catalog**

The Music / Video Catalog enables user to browse music and video contents (media contents) stored on the phone/MMC by different criterias:

- Artist
- Album
- Playlist
- Genre
- All files

The catalog is built parsing ID3 Tags ver 1.1 on media files.

At the first run the catalog is empty; to populate it use Menu -> Search for media files.

To select a category:

- Press Menu -> Select, or
- Press Ok, or
- Press right arrow.

To go back:

- Press right softkey "Back", or
- Press left arrow

### **1.3.1. Menu description**

- Go to Player: Shortcut to Media Player commands view. Displayed only if there is a playlist previously loaded;
- Select: Open the highlighted category;
- Delete Playlist: Visible during Playlist category browsing. Delete the highlighted playlist. Alternatively use "C" key;
- Search for media files: Scan c:\system\mail, c:\Nokia and memory card, if available, to look for mp3, mp4, m4a, 3gp, aac, wav files;
- Default skin: Set the default application background;
- Register: On trial version display dialog to insert registration number. Not shown after registration;
- Help: Display context sensitive help;
- Exit: Close the application.

### **1.4. How to play or save media selection**

Browsing on Music / Video Catalog finally a list of media contents is displayed. This is a multiselection list where you can select your favourite media to be played.

To play the selection:

1. Press right arrow key. A confirmation dialog ask whether load the selection, press Yes and Media player view is displayed;
2. Press Menu -> Selection -> Play...

A confirmation dialog ask whether load the selection, press Yes and Media player view is displayed

To save the selection:

1. Press Menu -> Selection -> Save...

Enter name of playlist to be saved in the dialog, press Ok.

To modify and look at the saved playlist content, go back to Music / Video Catalog and browse in to Playlist category.

To add selection to a previous saved playlist:

1. Press Menu -> Selection -> Add to...

Select the playlist where to add selected contents from the dialog.

#### **1.4.1. Menu description**

- Go to Player: Shortcut to Media Player commands view. Displayed only if there is a playlist previously loaded;
- Select / Deselect:
  - Select: Add the highlighted item to the selection
  - Select all: Add all items to the selection
  - Deselect: Remove the highlighted item from the selection
  - Deselect all: Remove all items from the selection
- Selection
  - Play: Play the selection
  - Save: Save the selection
  - Add to: Add the selection to a saved playlist

- Media details: Show information concerning the highlighted file as such as dimension and location.

## **1.5. How to use Media player**

When a saved playlist or a music selection from Music / Video Catalog is playing, the Media player view is displayed.

### **1.5.1. Player commands**

The player commands are displayed as a bar on top of softkeys; use left and right arrow keys to highlight a command and Ok button to select it.

Player commands are, from the left to right of the screen:

- Repeat Mode:
  - ALL: Play the selection from top to bottom item;
  - MIX: Play the selection in a random order;
  - ONE: Play always the current song.
- Skip Back: Play the previous song;
- Rewind: Go 10 second back;
- Play/Pause: Play/pause the current song;
- Stop: Stop playback;
- Forward: Go 10 second forward;
- Skip Next: Play the next song;
- Lock: Lock the keyboard.

### **1.5.2. Volume control**

The volume control is displayed between the softkeys.

To switch focus between player commands and volume controls use up and arrow keys.

Use right arrow key to increase volume;

Use left arrow key to decrease volume.

### **1.5.3. Music Mode**

The current media is an audio file.

The following information are displayed:

- the artist name
- song title
- position into selection
- number of media into the playlist;
- Duration;
- Elapsed time.

#### **1.5.4. Video Mode**

The current media is a video file. The title is displayed at the bottom of the area where video is playing.

Use left arrow key to toggle between normal and fullscreen mode.

#### **1.6. Trial version limitations**

The application is protected using a IMEI based algorithm.

Before registration, two limitations restrict player functionalities:

- Playback maximum time is 1 (one) minute;
- Total playback time is 30 (thirty) minutes.

To register the application, open Menu -> Register and insert 5-digits registration numbers into the dialog.

To purchase the software visit : [moremedia.omniaway.com](http://moremedia.omniaway.com) and click the link to [handango.com](http://handango.com).

To retrieve IMEI code, digit \*#06# on your phone.

For further informations on Omniaway products visit :

<http://www.omniaway.com>